



Illustrated Parts List Model Series 31M700

TYPE NUMBERS 0101 THROUGH 0237


TABLE OF CONTENTS


Air Cleaner	5
Alternator	7
Blower Housing	5
Camshaft	2
Carburetor	4
Controls	7
Crankshaft	2
Cylinder	2
Cylinder Head	3
Electric Starter	7
Engine Sump	2
Flywheel	6
Fuel Supply	4
Gasket Set – Engine	2
Gasket Set – Valve	3
Governor Spring	7
Ignition	7
Kit – Carburetor Overhaul	4
Lubrication	3
Piston, Rings, Connecting Rod	2
Valves	3





PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.












1036 EMISSIONS LABEL







REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1		Cylinder Assembly	26	791936	Ring Set	81		Lock-Muffler Screw
2	399265	Kit-Bushing/Seal			(Standard)	93		Bushing-Throttle Shaf
		(Magneto Side)			(Used After Code Date	94		Kit-Idle Mixture
3	★391086 s				06010100).	94A	695425	Kit-Idle Mixture
		(Magneto Side)			Note	95	● 691636	Screw
4A		Sump-Engine			792649 Ring Set			(Throttle Valve)
5		Head-Cylinder			(.020" Oversize)	95A	●690718	
7		Gasket-Cylinder Head			(Used After Code Date			(Throttle Valve)
9		Gasket-Breather			06010100).	98		Kit-Idle Speed
10	697157				699051 Ring set	98A		Kit-Idle Speed
		(Breather Assembly)			(Standard)	104		Pin-Float Hinge
11		Tube-Breather			(Used Before Code	104A		Pin-Float Hinge
12	★ 697110	Gasket-Crankcase			Date 06010200).	105		Valve-Float Needle
		(.015" Thick)			697559 Ring Set	105A		Valve-Float Needle
		(Standard)			(.020" Oversize)	106	●690577	Seat-Inlet
13	793988				(Used Before Code			(Gravity Feed)
		(Cylinder Head)			Date 06010200).			Note
		(Used After Code Date	27	698469	Lock-Piston Pin			●691780 Seat-Inlet
		07011400).	28	697099	Pin-Piston			(Pump Feed)
		Note	29	791632	Rod-Connecting	108		Valve-Choke
		690360 Scew			(Standard)	108B		Valve-Choke
		(Cylinder Head)			Note	117	●694352	Jet-Main
		(Used Before Code			697264 Rod-	4474	- 600 457	(Standard)
15	600046	Date 07011500).			Connecting	117A	●699457	Jet-Main
15	090940	Plug-Oil Drain (Square Head)			(.020" Undersize)	440	607000	(Standard)
		Note			(Used Before Code	118	09/228	Jet-Main
		691680 Plug-Oil Drain			Date 05040400).	118A	600/59	(High Altitude) Jet-Main
		(Square Socket)	32	791118	Screw	IIOA	099436	(High Altitude)
		Used on Type No(s).			(Connecting Rod)	121	697241	Kit-Carburetor
		0215.	33		Valve-Exhaust		007241	Overhaul
16	697516	Crankshaft	34		Valve-Intake			(Walbro)
20	★791892	Seal-Oil	35	691279	Spring-Valve	121A	699521	Kit-Carburetor
		(PTO Side)			(Intake)			Overhaul
22	692125	Screw	36	691279	Spring-Valve			(Nikki Carburetor)
		(Crankcase			(Exhaust)	125	791888	Carburetor
		Cover/Sump)	37		Guard-Flywheel			(Walbro)(Gravity Feed
23	693557	Flywheel	42		Keeper-Valve	125A	792358	Carburetor
		Used on Type No(s).	43		Slinger-Governor/Oil			(Nikki)(Gravity Feed)
		0215, 0234.	45		Tappet-Valve Camshaft			
		Note	46 50		Camsnaπ Manifold-Intake			
		693556 Flywheel	50		Manifold-Intake 7 Gasket-Intake			
		Used on Type No(s).	51★∆ 53	690227				
		0101, 0111, 0112,	33	030221				
0.4	000000-	0167, 0237.	54	691148	(Carburetor)			
24		Key-Flywheel	34	091148	(Intake Manifold)			
25	19200/	Piston Assembly	73A	494430	Screen-Rotating			
		(Standard) Note	73A 74	691674	•			
		792648 Piston	'-	331014	(Rotating Screen)			
		Assembly	78	691003				
		(.020" Oversize)			(Flywheel Guard)			
		·			·			
								asket Set_Ref No. 97

 [◆] Included in Carburetor Gasket Set-Ref. No. 977.
 ∆ Included in Valve Gasket Set-Ref. No 1095.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
127	695005	Plug-Welch	265	691024	Clamp-Casing	356	607020	Wire-Stop
				695134		330	097009	· ·
127A		Plug-Welch	267	095134				Used on Type No(s).
130		Valve-Throttle			(Casing Clamp)			0101, 0111, 0167,
130A		Valve-Throttle			Note			0237.
131		Kit-Throttle Shaft			690804 Screw	358		Gasket Set-Engine
131A	699501	Kit-Throttle Shaft			(Casing Clamp)	363	19203	Puller-Flywheel
133	494381	Float-Carburetor			Used on Type No(s).	383	89838s	Wrench-Spark Plug
133A	694914	Float-Carburetor			0101, 0111, 0112.	385	694476	Screw
135	698780	Tube-Fuel Transfer	268	691025	Casing-Control Wire			(Fuel Pump)
		(Nikki)(Gravity Feed)	200	031020	(Cut To Required			Used on Type No(s).
		Note						0111, 0112, 0167.
		792022 Tube-Fuel		001000	Length)	385A	690297	
		Transfer	269	691026	Wire-Control	3634	090291	
					(Cut To Required			(Fuel Pump)
		(Nikki)(Pump Feed)			Length)			Used on Type No(s).
137●		Gasket-Float Bowl	270	691027	Nut			0111, 0112, 0167.
137A	●698781	Gasket-Float Bowl			(Control Wire Casing)	387	697090	Pump-Fuel
141	790902	Kit-Choke Shaft	271	691028	Lever-Control			Used on Type No(s).
141B	695420	Kit-Choke Shaft			Washer-Sealing			0111, 0112, 0167.
142	●697140	Nozzle-Carburetor	276A		Washer-Sealing	387A	808656	Pump-Fuel
		(Standard)			•			Used on Type No(s).
146	691639	Key-Timing	300	697349				0111, 0112, 0167.
187B		Line-Fuel			Used on Type No(s).	404	691691	Washer
1075	191005	(Formed)(10–1/4			0111.		031031	(Governor Crank)
			300A	698356	Muffler	415	690283	` '
		Inches Long)(Cut to			Used on Type No(s).	415	090203	9
		Required Length)			0112.		007400	(Engine Sump)
188	691693		304	790009	Housing-Blower	431		Elbow-Intake
		(Control Bracket)			(Black)	445	697153	Filter-Air Cleaner
192		Adjuster-Rocker Arm	305	697102	` ,			Cartridge
202	691841	Link-Mechanical	303	097 102				(Washable)
		Governor	0054	607400	(Blower Housing)	462	691261	Washer
209	692208	Spring-Governor	305A	697103				(Starter Cable)
		Note			(Blower Housing)	474A	696459	Alternator
		790602 Spring-	306		Shield-Cylinder			(Dual Circuit)
		Governor	307	691003				Used on Type No(s).
		Used on Type No(s).			(Cylinder Shield)			0215, 0234.
		0112.	309	693551	Motor-Starter	474B	696457	Alternator
216	601940	Link-Choke	310	690323	Screw	7,75	000-107	(Tri Circuit)
222		Bracket-Control			(Starter Motor)			Used on Type No(s).
			311	497608	Brush Set			0101, 0112, 0237.
227	091374	Lever-Governor	333		Armature-Magneto	474C	606450	Alternator
000	604040	Control	334	691061	<u> </u>	4740	090436	
232		Spring–Governor Link	334	091001				(10 Amp Circuit)
238		Cap-Valve	227	4010EE-	(Magneto Armature)			Used on Type No(s).
240	394358s	Filter-Fuel	337	49 1055S	Plug-Spark			0111, 0167.
		(White, 75 Microns)			Used on Type No(s).	480	693675	
		Used on Type No(s).			0101, 0112, 0215,			(Tube Clamp)
		0101, 0215, 0234,			0234.			
		0237.			Note			
240B	695666	Filter-Fuel			691043 Plug-Spark			
	_	(Includes 30 Micron			Used on Type No(s).			
		Paper Element)			0167, 0237.			
		Used on Type No(s).	344	693675				
1		0111, 0112, 0167.	J	090010				
		0111, 0112, 0107.			(Cable Clamp)			
1								
1								
						L		

[★] Included in Engine Gasket Set-Ref. No.358.
◆ Included in Carburetor Overhaul Kit-Ref. No. 121 or 121A.

Included in Carburetor Gasket Set–Ref. No. 977.
 Δ Included in Valve Gasket Set–Ref. No 1095.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
501	691188	Regulator	584	697112	Cover-Breather	789A	698329	Harness-Wiring
		Used on Type No(s).			Passage			Used on Type No(s).
		0101, 0112, 0237.	601	791850	Clamp-Hose			0215, 0234, 0237.
		Note	613	691416	Screw	797	693167	Nut
		691185 Regulator			(Muffler)			(Brush Retainer)
		Used on Type No(s).	613A	690297	Screw	801	691283	Cap-Drive
503	601522	0111, 0167. Strap-Starter			(Muffler)	802	691286	Cap-End
505	691251		613B	691678	Screw	803		Housing-Starter
303	031231	(Governor Control			(Muffler)			(Not Serviced
		Lever)	614		Pin-Cotter			Separately, Order
510	693699	Drive-Starter	616		Crank-Governor			Starter Motor 693551)
513	692024	Clutch-Drive	617	★●692138	Seal-O Ring	823	698941	
521	690581	Shield-Cable			(Intake Manifold)			(Muffler Adapter)
523		Dipstick	634		Spring/Seal Assembly			Used on Type No(s).
524		Seal-Dipstick Tube	634B		Spring/Seal Assembly			0111, 0112.
525	697184	Tube-Dipstick	635		Boot-Spark Plug	830		Stud-Rocker Arm
		Used on Type No(s).	643		Retainer–Air Filter	832	790244	Guard-Muffler
		0101, 0112, 0215, 0234, 0237.	654	690958				Used on Type No(s). 0112.
		Note	6604	601500	(Carburetor)	926	691676	
		697085 Tube-Dipstick	668A	691500	•	836	091070	(Muffler Guard)
		Used on Type No(s).	676	307630	(Rotating Screen) Deflector-Muffler	836A	690367	` '
		0111, 0167.	070	397030	Used on Type No(s).	630A	090307	(Muffler Guard)
526	697088	Screw			0112.	842	+691031	Seal-O Ring
		(Regulator)	677	690661		542	×031001	(Dipstick Tube)
		Used on Type No(s).	"	030001	(Muffler Deflector)	847	790442	Dipstick/Tube
		0101, 0112, 0237.			Used on Type No(s).	"		Assembly
		Note 697348 Screw			0112.			Used on Type No(s).
		(Regulator)	691	* 692407	Seal-Governor Shaft			0101, 0215, 0234,
		Used on Type No(s).	692		Spring-Detent			0237.
		0111, 0167.	697	690372				Note
527	698467	Clamp-Tube			(Drive Cap)			790443 Dipstick/Tube
544		Armature-Starter	718	690959	Pin-Locating			Assembly
552	697144	Bushing-Governor	729	691335	Clip-Wire			Used on Type No(s).
		Crank			(Wire Saddle)			0111, 0112, 0167.
559	697561		729A	691224	Clip-Wire	851		Terminal-Spark Plug
		(Remote Choke Stop)			(Aluminum Coated	864	697346	Adapter-Muffler
		Used on Type No(s). 0111, 0237.			Steel)			Used on Type No(s).
		Note	741		Gear-Timing			0111, 0112.
		693675 Screw	750	790832				Seal-Valve
		(Remote Choke Stop)		607607	(Oil Pump Cover)	877	393456	Wire/Connector–Altern
		Used on Type No(s).	757 750		Link-Counterweight			ator
		0112.	758 750		Counterweight	077D	202527	(Dual Circuit)
562	691119		759 783		Pin-Counterweight Gear-Pinion	877B	39333 <i>1</i>	Wire/Connector–Altern ator
		(Governor Control	789		Harness-Wiring			(Tri Circuit)
570	602206	Lever) Wire Assembly	109	U32U3/	Used on Type No(s).	877C	399916	Wire/Connector-Altern
578 579	691029				0101, 0111, 0112,	5,,5	555510	ator
2.0	55.025	(Starter Cable)			0167.			(10 Amp Circuit)
		·						
			<u> </u>		. Incl	Ludod in Co	rhuratar G	asket Set-Ref. No. 977.

 [◆] Included in Carburetor Gasket Set-Ref. No. 977.
 ∆ Included in Valve Gasket Set-Ref. No 1095.

								3 1 101 7 00
REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
878	398661	Harness-Alternator	1022 * .	∆ 272475 s	Gasket-Rocker Cover	1090	691293	Retainer-Brush
		(Dual Circuit)	1023	791079	Cover-Rocker	1091	691333	Cap-Limiter
878A	691955	Harness-Alternator	1024	499054	Pump-Oil	1095	690190	Gasket Set-Valve
		(Tri Circuit)	1026	692003	Rod-Push	1119	691183	Screw
883	692236	Gasket-Exhaust			(Intake)			(Alternator)
914	691108				Note	1127	695407	Screw
		(Rocker Cover)			692011 Rod-Push			(Float Bowl)
918	791851	Hose-Vacuum			(Exhaust)	1263	697124	Reed-Breather
		Used on Type No(s).	1027	696854	Filter-Oil	1264	697104	
		0111, 0112, 0167.	1029		Arm-Rocker			(Breather Reed)
943	★690589	Seal-O Ring	1034		Guide-Push Rod	1265	697125	Support-Blower
		(Oil Pump Cover)	1035		Shaft-Pump			Housing
947		Solenoid-Fuel	1036	000104	Label-Emissions	1266	★●691917	Seal-O Ring
947A		Solenoid-Fuel	1000		(Available From A			(Intake Elbow)
950		Screw-Float Bowl			Briggs & Stratton	1266A	★●697123	Seal-O Ring
965		Cover–Oil Pump			Authorized Dealer)			(Intake Elbow)
967		Filter-Pre Cleaner	1040A	602/70	Plate-Trim	1267		Latch-Blower Housing
968		Cover-Air Cleaner	1040A 1044	698139		1270	697156	Plug-AVS
975		Bowl-Float	1044	050139	(Flywheel)			Counterweight
975A		Bowl-Float	1051	601265	Ring-Retaining	1279	691108	
977		Gasket Set-Carburetor	1051		Tie-Cable			(Blower Housing
987		Seal-Throttle Shaft				4000	0=04.4=	Support)
987A		Seal-Throttle Shaft	1058		Operator's Manual	1330	2/214/	Repair Manual
1005		Fan-Flywheel	1059		Kit-Screw/Washer			
1017	690770	Screen-Oil Pump	1070	690372				
		(Push In)			(Flywheel Fan)			

[★] Included in Engine Gasket Set-Ref. No.358.
◆ Included in Carburetor Overhaul Kit-Ref. No. 121 or 121A.

Included in Carburetor Gasket Set–Ref. No. 977.
 Δ Included in Valve Gasket Set–Ref. No 1095.